

# BACK AND BODY MASSAGER WITH INTEGRATED SEAT WARMER

## User Guide



### WARNING

- If you want to turn off the massager, press POWER BUTTON first, then unplug the 12V power adapter. If you want to restart, please wait 5 seconds.
- Store the remote control and 12V power adapter in a safe and dry place when no longer in use.
- Do not use while bathing or in the shower.
- Do not place or store the massager where it can fall or be pulled into the bathtub or sink.
- Do not place or submerge in water or other liquids.

### TIMER FUNCTION FOR SAFETY

Automatically switches off when heating for over 34 minutes and also when massaging for over 17 minutes. Please wait 5 seconds before turning the massager back on after it has automatically switched itself off.