

3-in-1 Hot Brush Overview



Simply Brands

3-in-1 Volumising Hot Brush

USER MANUAL

Model: 5250 SKU: SBA-00076





CAUTION: For your safety, please read this user manual carefully and thoroughly before using this product.

Please keep this manual somewhere safe for future reference.

Simply Brands

Importer Name:

mply Brands (Asia) Ltd

Importer Address:

Init 04-05, 16th Floor, The Broadway No. 54-62 ockhart Road Wanchai Hong Kong

Made in China

- Product Name:
 3-in-1 Volumising Hot Brush
- Product Model: 5250
- Charging Voltage/Current: AC 220V-240V
- Frequency50-60Hz
- Power: **1200W**



Hot Brush Features

This user manual provides safety instructions and important tips for using and caring for your new 3-in-1 Volumising Hot Brush.

- Tourmaline technology emits negative ions for healthier hair. The tourmaline even helps to seal moisture into your hair and counteracts frizz.
- . Ultra lightweight body that makes it easy to carry when travelling.
- Quiet and powerful 1200 watt motor.
- . 60% faster drying time compared with other blow dryer brushes.
- 3 variable heated speed settings for total control. It's also fast to heat-up once you've switched it on.
- · Ceramic coated brush head that helps protect your hair with even heat distribution.

Safety Instructions

To correctly and safely use the hot brush, it is very important that you follow the instructions below thoroughly prior to use. Please save these instructions for future reference

- Brush Head/Bristle area will be very hot. DO NOT TOUCH THIS AREA WHILE THE BRUSH IS ON.
- This appliance should never be left unattended when it is plugged in. Close supervision is necessary when appliance is used by or near children or individuals with certain disabilities.
- . Keep out of reach of children.
- . Do not use the hot brush if any part is chipped or cracked upon an initial visual inspection of it.
- Do not use the hot brush if it is defective or the power cable is damaged. If the brush is not working properly, please first check the plug and then check that the main electic supply is actually switched on.
- **NEVER** use the hot brush in water or other liquids.
- **NEVER** use the hot brush near a bathtub, shower. containers full of water, or any other damp place.
- . NEVER use when your hands or feet are wet.
- . NEVER reach for the hot brush if it has fallen into water. Switch off the power supply at the main socket, then unplug it.

- Do not use the hot brush near aerosol cans. spray products or other toiletries.
- · Always be careful not to burn yourself while usina it.
- · Do not use the device for any other purpose than its intended use.
- Do not use with a voltage converter.
- Before carrying out any cleaning or maintenance. please be sure the hot brush is unplugged and that it's completely cooled down.
- . The hot brush features an integrated UK plug. If it's unable to power on, please check the socket button is switched on as well as the plug has been properly plugged in.
- . **NEVER** operate without the rear filter on.
- . **NEVER** block the air opening of the hot brush or place it near or on a soft surface which may block its air openings.
- NEVER use the hot brush if it's been left outdoors. or submerged in water.
- If the hot brush is equipped with attachments. please allow these to cool if these have been recently used prior to re-attaching or removing attachments on/off the brush.
- · No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

Maintenance and Care

- Always unplug the hot brush and allow it to cool if necessary prior to cleaning it.
- Periodically inspect the air intake/filter screen on the back of the hot brush and remove any debris that may have accumulated. Build up may reduce air flow and damage the brush.
- · Never use the following chemicals to clean the hot brush: thinners, gasoline, types of alcohol such as surgical spirit, or any other flammable chemicals.
- DO NOT wrap the power cable around the hot brush as this may cause the cable to wear out.
- . Just use a soft, dry cloth to clean the hot brush.

Operating Guidelines

- · Prior to plugging in, check the voltage on the rating label to ensure it's compatible with the power socket's voltage.
- Your hot brush is equipped with three heat settings - Low, Middle and High. It's also equipped with a control switch. As a general guide, use the high speed setting to effectively dry thicker/very wet hair, and the middle setting for finer/partly dry hair and also more precise drying control when styling. The low setting can be used towards the latter stages in styling your hair on a less powerful mode.
- · Section your hair and dry one area at a time. Start at the back of your head when drying wet hair and gradually work towards the front.
- DO NOT concentrate the airflow on any one area for an extended period of time to avoid causing split ends and overly dry hair/scalp.
- . BE CAUTIOUS: begin with the low setting first to test the right temperature for your scalp.

NOTE: during the first few minutes of initial first use, you may notice smoke and a slight odour from the hot brush. This is quite normal and will quickly disappear.

Download the instructions in other languages

Mode d'emploi en Français



Instrukcja w języku polskim





