

WiFi IP CAMERA

A Quick Manual for
Android and iOS Devices

Product List:

After you open your product, please check that the product and accessories resemble the images below:



Camera



WiFi Antenna - May change depending on model.



Waterproof Cap

Product Features:



Operation:

1 - Download the App




2 - Turn on the camera


Install the TF card and connect the camera to the power outlet.

3 - Camera Configuration

Option 1 - Wireless Network Configuration:




1) Open the App and click 'Login'. If you do not have an account, you will need to register first.



2) Click the '+' symbol in the top right-hand corner.

Option 1 Continued...




3) Click 'add device'. Choose your Wifi router and enter the router password.



Operation:

Option 1 Continued...



4) After you hear 'Connect Successfully', you will be asked to enter a password.

5) Click 'confirm' and enter a Username.

7

Option 1 Continued...




6) Click 'Save' and you will be brought to a video preview. Your connection is now successful.

8

3 - Camera Configuration

Option 2 - Wired Network Configuration:



1) After logging in, click the '+' icon in the top right hand corner of your device. Select the third option 'Add device in the same WLAN'.

2) Click 'Device Searching Interface' then click 'xmjp_bullet_****'.

3) The camera will now show as 'online' which indicates the connection was successful.

4) You can click on the product icon to change settings.

9

FAQ:

Q - How do you save videos on the camera?

A - The camera supports FAT32G format Class6, Class10, TF Card with a maximum memory of 128G. When the memory on the TF card is full, it will delete the oldest video automatically and loop recording.

Q - How do you restore to factory settings?

A - Open camera settings by following 'Settings – General – About Equipment' and click 'Restore Factory Settings'. IMPORTANT: Do not turn off the camera during this process.

Q - The camera is offline - what do I do?

A - 1) Check the power source and the Wifi connection. 2) Restart your camera. 3) Reconfigure your camera.

10

Notice:

Whilst using the camera, please amend the user password for your own security. Please ensure when installing the equipment, your environment is dust and damp free.

Updates:

Please ensure you update the App when prompted to do so.

Simply Brands

www.simply-brands.com

Importer Name:
Simply Brands (Asia) Ltd

Importer Address:
Room 605, 6/F, Fa Yuen Commercial Building,
75-77 FaYuen Street, Mongkok, Kowloon, HK

Model Number:
A8

Country of Origin:
Made in China

Please retain this information for future reference.



11